



<b>Product Description:</b>	Ultimate Chopper Food Processor
<b>Manufacturer:</b>	Ultimate Chopper, LLC
<b>Date Recall Posted:</b>	09/08/05
<b>UPC:</b>	8-55209-00054-8
<b>Summary Of Recall:</b>	The interlocking lid assembly on the appliance can malfunction, allowing the food processor to be operated when the lid is off. This can result in a laceration or finger tip amputation hazard if consumers insert their hands into the food processor.
<b>What You Should Do:</b>	Consumers should immediately inspect their Ultimate Chopper food processor to determine if the interlocking lid is functioning properly. Consumers should remove the lid and blade assembly and test to see if the unit will operate without the lid on. If the unit turns on when the lid is removed, consumers should stop using it immediately and contact Ultimate Chopper LLC to receive a free replacement unit. Also, if blade assemblies are worn, damaged or broken for any reason, consumers should stop using the unit and contact the company to receive a free replacement blade assembly. Consumers also can access an instructional video demonstrating how to inspect their Ultimate Chopper at <a href="http://demo.ultimatechopper.com">http://demo.ultimatechopper.com</a>