



**Product Description:**

Hamilton Beach® and Proctor-Silex® Toasters

The recalled Hamilton Beach® and Proctor-Silex® toasters are black, red, white, chrome or brushed chrome with 2-slice or 4-slice openings. Hamilton Beach or Proctor-Silex is printed on the side of the toasters. Only specific series codes of each model are included in this recall. The model number and series code are printed on the bottom of the toasters.

Toaster Model Numbers	
22145B	22779
22145BC	22900
22450	22903
22559	22903H
22625	24450
22627C	24559
22635	24657
22657	24779
22658	



**Manufacturer:** Hamilton Beach Brands Inc., of Glen Allen, Va.  
Manufactured in China

**Date Recall Posted:** 2/14/08

**MEIJER UPCs:** UPC KEY

0-40094-22559-0	83
0-40094-22657-3	83
0-40094-24559-8	83
0-40094-24657-1	83

**Summary of Recall:** The toasters can remain “on” (energized) after popping up, and can ignite flammable items covering or in contact with the toaster, posing a fire hazard.

**What You Should Do:** Consumers should immediately stop using the recalled toasters and contact Hamilton Beach for instructions to receive a free replacement toaster.

**Consumer Contact:** For additional information, contact Hamilton Beach at (800) 574-6800 anytime, or visit the firm’s Web site at [www.hamiltonbeach.com](http://www.hamiltonbeach.com) for Hamilton Beach® toasters, and [www.proctorsilex.com](http://www.proctorsilex.com) for Proctor-Silex® toasters.