

## User Manual

**1.5" DIGITAL FRAME KEYCHAIN**

# USER MANUAL


## 1. Product brief introduction


DPFmate is specifically PC-software design for small screen digital photo frames, it achieves downloading pictures form the PC into a variety of digital photo added a series of humanization appended functions.


Characters as follows:

- (1) Pictures preview
- (2) Zoom in/out, Crop, Rotate editing abilities
- (3) Single, Sequence, Select mode delete pictures
- (4) Read and save pictures of DPF

1. There are four key, up key, menu key, Down key and reset key.

Press on key  UP key to preview previous one picture

Press on key  Down key to preview next one picture

Press on key  MENU key to main menu, power on/off the terminal

Long press on MENU key to power on the terminal, into interface show up picture, as the following picture, you can get the ability of the power and the index of picture.

Press MENU key to main menu, as following picture Press MENU key into child menu

Main Menu
USB Connect
Slide Show
Auto Off
Power off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit

USB Connect
Yes
No

Press “up” key or “Down” key select “Yes” or “No”, Select “Yes” ,then press “menu” key to Connect PC, and then load photos, finishing selection press “menu” key to save the configuration and exit.
---

2. Press “MENU” Key into child menu.

Main Menu
USB Connect
Slide Show
Auto Off
Power off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete one

Slide Show
03 Sec

Press “up” key or “Down” key select Configure time ,Configuration time between “00-15” second effective, finishing selection press “menu” key to save the configuration and exit
---

Delete All  
Exit

Press “up” key or “Down” key select Configure time, Configuration time between “00-15” minute’s effective, finishing selection press “menu” key to save the configuration and exit.

3. “AUTO Off” auto power off configuration, select third stem “Auto off”

Press “MENU” key into child menu

Main Menu  
USB Connect  
Slide Show  
Auto Off  
Power off  
LCD Contrast  
Backlight  
Display Clock  
Set Clock  
Delete one  
Delete All  
Exit

Auto off  
02 Sec

Press “up” key or “Down” key select Configure Auto Off, Configuration time between “00-30” minute’s effective, finishing selection press “menu” key to save the configuration and exit.

Press “up” key or “Down” key select Configure “Power off” time, configuration time between “00-30” minutes effective, and finishing selection press “MENU” key to save the configuration and exit. When time is zero minute, User must power off by hand

4. “LCD Contrast” configure screen contrast, select fifth stem “LCD Contrast”

Press “MENU” key into child menu.

Main Menu  
USB Connect  
Slide Show  
Auto Off  
Power off  
LCD Contrast  
Backlight  
Display Clock  
Set Clock  
Delete one  
Delete All  
Exit

LCD Contrast  
02 Sec

Presses “up” key or “Down” key select configure contrast value, configuration value between “01-06” effective levels.

5. "Backlight" configures screen height, select sixth stem "Backlight"  
Press "MENU" key into child menu

```

Main Menu
USB Connect
Slide Show
Auto Off
Power off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete one
Delete All
Exit
  
```

```

Backlight
11
  
```

Press "up" key or "Down" key select configure backlight value, configuration value between "01-21" effective levels, finishing selection press "MENU" key to save the configuration and exit

6. Display Clock

Clock function , select seventh

Press "MENU" key into menu . Examines Watching time

```

Main Menu
USB Connect
Slide Show
Auto Off
Power off
LCD Contrast
Backlight
Display Clock
Set Clock
Delete One
Delete All
Exit
  
```

```

04-17-2008
14:22:15
Monday
  
```

"Display  
y Clock" is to show clock and calendar

Users to need to configure time , when USB connected , the terminal can update PC time

7. Set Clock

Set Clock t function, select eighth

Press "NENU" key into child menu, set clock

```

Main Menu
USB Connect
Slide Show
Auto Off
Power off
  
```

```

04-17-2008
14:25:40
THU
  
```

LCD Contrast  
 Backlight  
 Display clock  
 Set Clock  
 Delete One  
 Delete All  
 Exit

Press “up” key or “Down” key select time and calendar , finishing selection press “MENU” key to save the configuration and exit

8. Delete one picture , first stop at the picture to he deleted press “ MENU” key into main menu select ninth stem “Delete One” as following ,then press “MENU” key to delete the picture . press “MENU” key into child menu

Main Menu  
 USB Connect  
 Slide Show  
 Auto Off  
 Power off  
 LCD Contrast  
 Backlight  
 Display Clock  
 Set Clock  
 Set Clock  
 Delete One  
 Delete All  
 Exit

Delete One  
 Yes  
 No

Select “Yes”, then press “menu” key to delete the picture ,  
 Select “NO”, exit.


9. delete all picture , select tenth stem “Delete All” , if users want to update all picture , select this stem , pies “MENU” key , Press “MENU” key into child menu

Main Menu  
 USB Connect  
 Slide Show  
 Auto Off  
 Power off  
 LCD Contrast  
 Backlight  
 Display Clock  
 Set Clock  
 Delete One  
 Delete All  
 Exit

Delete All  
 Yes  
 No

Select “Yes” , and then press “menu” key , the digital photo frame’s pictures will be delete forever , Select “NO” exit.

10. Last stem ,exit the main menu



Select “exit” , press “MENU” key to exit main menu go back picture display interface.

After connects P C the operational order

1、 Setting

Setting menu background color and font color

2. Save

Save all of choosed photos

3. Save all

Save all of photos

4. Exit

Exit

5. Download

Download photos into photo frame

6. ALL

Choose all of photos

7. Delete

Delete all of choosed photos

8. +

Zoom in the photo

9. –

Reduce the photo

10. Rotate

Contra rotate L 90°

11. Rotate

Clockwise rotation R 90°

12. Clear

Choose full page photo

13. Rect

Choose photo in the rectangle area coverage

14. Add

Add will download photo to right area coverage

## **GFM Guarantee**

If you are not totally satisfied with this GFM product, you may return it to any Meijer store for a full refund within 6 months (180 days) of purchase when accompanied by a receipt.

For customer support, please call (866) 845-9436 or go to [www.gfmproducts.com](http://www.gfmproducts.com).

**Dist. by Wholesale Merchandisers, Inc.,  
2929 Walker, NW,  
Grand Rapids, MI 49544  
Made in China**